



DEPARTURE ROUTE DESCRIPTION (Continued)

TAKE-OFF RWY 06R: Climb on runway heading. Thence . . .

BRUNO 1B (BRUNO1B): to intercept and follow SSJ VOR/DME R-073 until SSJ 9 DME. Turn right to follow MJV VOR/DME 15 DME Arc direct to CASOL. Proceed on IBZ NDB track 257° direct to IBZ NDB. Direct to BRUNO. Maintain 4000, except as cleared by ATC.

DRAGO 1B (DRAGO 1B): until SSJ VOR/DME 5 DME. Turn left (Max 210 KIAS) to follow SSJ VOR/DME 7 DME Arc to INCAS. Proceed on SSJ 7 DME Arc to intercept and follow SSJ R-326, intercept and follow POS R-276 direct to DRAGO. Maintain 6000, except as cleared by ATC

ESPOR 1B (ESPOR 1B): until SSJ VOR/DME 5 DME. Turn left (Max 210 KIAS) to follow SSJ VOR/DME 7 DME Arc to INCAS. Proceed on SSJ 7 DME Arc to intercept and follow SSJ R-326 direct to ESPOR. Maintain 6000, except as cleared by ATC. Cross SSJ 45 DME at or above FL80.

GALAT 1B (GALAT 1B): until SSJ VOR/DME 5 DME. Turn left (Max 210 KIAS) to follow SSJ VOR/DME 7 DME Arc to INCAS. Proceed on SSJ 7 DME Arc to intercept. and follow SSJ R-326, intercept and follow POS R-285 direct to GALAT. Maintain 6000, except as cleared by ATC.

IBIZA 3B (IBZ 3B): to intercept and follow SSJ VOR/DME R-073 until 9 DME. Turn right to intercept and fly MJV VOR/DME 15 DME Arc direct CASOL. Proceed on IBZ NDB. Track 257° direct to IBZ NDB. Maintain 4000, except as cleared by ATC

ISTER 1B (ISTER1B): to SSJ VOR/DME 5 DME. Turn left to follow SSJ R-063 direct TONIS. Turn right to intercept MHN VOR/DME R-264 direct to MHN VOR/DME. Direct to ISTER. Maintain 4000, except as cleared by ATC.

MAHON 3B (MHN 3B): to SSJ VOR/DME 5 DME. Turn left to follow SSJ R-063 direct TONIS. Turn right to intercept MHN VOR/DME R-264 direct to MHN VOR/DME. Maintain 4000, except as cleared by ATC

MEBUT 1B (MEBUT 1B): to intercept and follow SSJ VOR/DME R-073 until SSJ 9 DME. Turn right to intercept and fly MJV VOR/DME 15 DME Arc direct CASOL. Proceed on IBZ NDB track 257° to intercept and follow MJV R-212 direct MEBUT. Maintain 4000, except as cleared by ATC

MEROS 3B (MEROS 3B): to SSJ VOR/DME 5 DME. Turn left to follow SSJ R-063 direct TONIS. Turn left to intercept and fly MJV VOR/DME R-050 direct to MEROS. Maintain 4000, except as cleared by ATC.

MORSS 1E (MORSS1E): to SSJ VOR/DME 5 DME. Turn left to follow SSJ R-063 direct TONIS. Turn right to intercept MHN VOR/DME R-264 direct to MHN VOR/DME. Direct to MORSS. Maintain 4000, except as cleared by ATC.

OSGAL 1B (OSGAL 1B): to intercept and follow SSJ VOR/DME R-073 until 9 DME. Turn right to follow MJV VOR/DME 15 DME Arc direct to CASOL. Turn left and follow MJV R-166 direct to OSGAL. Maintain 4000, except as cleared by ATC

TURIA 1B (TURIA 1B): until SSJ VOR/DME 5 DME. Turn left (Max 210 KIAS) to follow SSJ VOR/DME 7 DME Arc to INCAS. Proceed on SSJ 7 DME Arc to intercept and follow SSJ R-326, intercept and follow POS R-255 direct to TURIA. Maintain 6000, except as cleared by ATC.